


• Charging Solar 2200

To charge by USB 5V, please use the built-in USB cable and connect it to a standard USB port from a desktop PC or laptop.

To charge by the Solar Module, the solar charger module will automatically detect any available light source and charge the unit on a continuous basis.



• Empowered Hours



*The additional time may vary by devices and operating mode.

• Powering Mobile Devices via USB

To charge devices by using standard USB, please use the USB charging cable to connect your mobile devices to Solar2200's USB ports accordingly. It could charge two mobile devices at the same time via dual USB ports.



1 I-Back Solar2200

2 USB to Micro USB cable

Northern California Office

SPARKLE POWER INC.
1000 Rock Ave. San Jose, CA95131 U.S.A
TEL: +1-408-519-8888 / FAX: +1-408-519-9999
sparkle@sparklepower.com / www.sparklepower.com

Southern California Office

17071 Green Drive City of Industry, CA 91745
TEL: +1-626-839-7180 / FAX: +1-626-839-3395
sparkle@sparklepower.com / www.sparklepower.com



www.sparklepower.com